

Replacement parts of the product will be provided at nominal cost (covering the cost price of the replacement parts only) to the customers after the Warranty Period has expired. We will cover the complete cost of sending replacement parts within the warranty period. After that, Nominal cost of the product & Actual shipping cost will be charged.

Donot send the unit to us without first getting a response and getting the approval to send back the item.

In case of any kind of dissatisfaction, we urge you to **Contact us** immediately and we shall do our best to help you out.

For any other assistance you can reach us via email.

FILMCITY

SL-2 DSLR Camera Slider



Setup and Operation Manual

All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

INTRODUCTION

The FILMCITY SL-2 Camera Slider is a professional piece of kit loaded with features and one of the lightest systems available in the market. The core purpose of this slider is to make a reliable camera slider for DSLRs as well as for camcorder use that can be packed down as small, and as light as possible.

DETAILS OF THE PACKAGE

You will receive the SL-2 Camera Slider unassembled in one bag. Unpack the bag and check whether you have received all the contents according to your purchase or not.

CONTENTS OF SHIPPING BOX:

- ◆ 2 x 2ft Sliding Rails
- ◆ 1 x Camera Mount Platform with Sliding Bush Technology.
- ◆ 2 x End Feet
- ◆ Packing bag



ASSEMBLING

STEP I:

Sliding rails and camera mount platform are already assembled together.



STEP II :


Take out the end feet provided in the packing. Now, loosen the tightening knob of the foot one by one. Insert the first foot to one side of the rails & tighten the knob. Likewise, insert the second foot to the other end of the rails.



STEP III:

Now take out the camera plate from the slider by pressing the knob and attach your camera on the camera plate with the help of ¼" screw provided and secure it with the screw driver .

Re-insert the camera plate again onto the slider.



Now , SL-2 Camera Slider is ready to use.

WARRANTY

We offer a limited time warranty for our products. For Mechanical products we provide a 6 month warranty & for electronic products we provide a 3 month warranty from the date of purchase.

We will repair or replace your product, free of charge, in the event of a defect in materials or craftsmanship obtained during normal use or handling based on the user manual. Please note that we will not cover any shipping costs for returning the product to us. If any VAT or import duties are applied to the return, we will also charge these costs to the customer.

The warranty does not include, by the way of example, damage caused by products that we donot supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product , or service by anyone other than our company.

We are not liable for incidental or consequential damages resulting from the use of the unit or occurring due to any breach of this warranty.