



4ft Linear Camera Slider (S4-4010) with Level Feet

INSTRUCTION MANUAL



All rights reserved

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the publisher.

INTRIDUCTION

For all those times a tracking shot would add production value to a scene but the platform was not part of your kit and it costs less than a three day rental. Our four feet camera linear slider can help you capture shots not possible with more traditional gear. Ground level framing is especially dramatic and when you add tracking moves, client screenings get you rave reviews.

IN THE BOX

Please inspect the contents of your shipped package to ensure you have received all that is pictured and listed below. The gray foam shipping /storage container has been especially designed to protect your purchase while in transit and is a good place to keep your slider when not in use.



4' Slider rail with Camera Mounting Plate



2 - End Stops





4 x Leveling feet



Accessory Kit

ASSEMBLING OF YOUR 4ft LINEAR CAMERA SLIDER

- Loosen the 3 grub screws located on the sides of the mounting plate just enough to allow for removal from the slider. Then slide the mounting plate off the rail in preparation for mounting the camera.




- Now attach camera to the mounting plate as shown. Return the mounting platform with the attached camera to the rails, by sliding it back on.



- Unscrew the washer on end stops in order to attach them to slider platform with the silver washer on top. Tighten the allen bolt with the supplied tool and secure the stopper.



- Un-screw one end of a leveling adjusters and slide it through the hole located in the end stopper. Make sure that tension knob is loose enough to easily slide the rod into the hole.



- Return the ball to the adjuster by screwing it back on to the post. Secure with tension knob. Using the same approach attach all level feet to end stopper shown below.



YOUR 4FT CAMERA LINEAR SLIDER ALL DRESSED UP AND READY TO GO



WARRANTY

(CAMERA NOT INCLUDED)

We offer a limited time warranty for our products. For Mechanical products we provide a 6 month warranty & for electronic products we provide a 3 month warranty from the date of purchase.

We will repair or replace your product, free of charge, in the event of a defect in materials or craftsmanship obtained during normal use or handling based on the user manual. Please note that we will not cover any shipping costs for returning the product to us. If any VAT or import duties are applied to the return, we will also charge these costs to the customer.

The warranty does not include, by the way of example, damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product , or service by anyone other than our company.

We are not liable for incidental or consequential damages resulting from the use of the unit or occurring due to any breach of this warranty.

Replacement parts of the product will be provided at nominal cost (covering the cost price of the replacement parts only) to the customers after the Warranty Period has expired. We will cover the complete cost of sending replacement parts within the warranty period. After that, Nominal cost of the product & Actual shipping cost will be charged.

Do not send the unit to us without first getting a response and getting the approval to send back the item.

In case of any kind of dissatisfaction, we urge you to **Contact us** immediately and we shall do our best to help you out.

For any other assistance you can reach us via email.